

New Part WOW Process - Metal



STEP 1: Clean and inspect panel. Use 3919S Prepsol and Audurra Degreasing Cloth.



STEP 2: If required, sand with Audurra Premium Sanding Disc C to remove imperfections in e-coat. If there are no imperfections or damage, go to step 3.



STEP 3: Scuff sand entire panel with Audurra Fleece Pad very fine (red)*.




STEP 4: Clean panel thoroughly. Use 3920S Degreaser and Audurra Degreasing Cloth.



STEP 5: Apply NS260x Non-Sanding Primer-Surfacer. Flash off.



STEP 6: If needed, remove dust inclusions by using Audurra Sanding Sponge Flex Ultrafine Blue.



*Due to the wide variety of electrocoats present on the market, its quality can differ a lot. For this reason preferably scuff sand the e-coat. Follow relevant Cromax product TDS's

This New Part WOW Process for Metal has been performed with products out of the Cromax product range.